

- 15 **DO NOT** attempt to remove the load or disconnect from the anchor when the rope is in tension.
- 16 **DO NOT** leave the winch unattended when it has a load on it and the rope is tensioned.
- 17 **DO NOT** attempt to use the winch if the rope starts to slip through it as the load is applied. Release the tension on the rope immediately.
- 18 **DO NOT** leave the wire rope in the winch after use. It must be stored on the reel supplied or in a coil to avoid damage or kinking.
- 19 **DO NOT** attempt repairs. Contact the Hire Company.