

- 16 Stop the engine before clearing a choked rotor.
- 17 **DO NOT** leave the engine running when the machine is left unattended.
- 18 **DO NOT** smoke when refuelling. **NEVER** refuel with the engine running.
- 19 Replace the fuel caps securely on the engine and fuel container. Wipe up any spillage immediately.
- 20 Fuel containers should be in good condition and leak proof.
- 21 **CHECK** that there is no combustible material on the exhaust system. The exhaust and silencer get very hot.
- 22 In the event of a leak of fuel or oil developing, switch the engine off immediately.
- 23 **DO NOT** attempt repairs. Contact the Hire Company.