



- 15 **CHECK** that there is no combustible material lying on or against the exhaust system. The exhaust pipe and silencer get very hot.
- 16 In the event of a leak of fuel or oil developing, switch the engine off immediately.
- 17 If warning lights show or gauges register outside normal limits, switch off the engine.
- 18 **DO NOT** top up with coolant while the engine is running. Allow the radiator to cool before removing the radiator cap.
- 19 **DO NOT** leave the engine running when the machine is left unattended.
- 20 Always ensure that the roller is parked in a safe situation.
- 21 **DO NOT** attempt repairs. Contact the Hire Company.